



Rymar Chew Stop is a natural pepper additive that may help prevent animals from chewing on wood. Chew Stop was also developed to help keep horses from cribbing. It **may** discourage bees, bugs, spiders, and birds—naturally as well.

Directions: Mix in thoroughly and apply paint or stain per manufacturer's instructions. One 2 ounce bottle contains enough Chew Stop to treat two gallons of paint or stain.

Notice: Chew Stop may slightly alter some colors, but will not affect the performance of the product it is added to. Test before using.

Caution: Keep out of reach of children. Do not take internally. Avoid contact with skin and eyes. Flush thoroughly with water if you come into contact with this product. Wear proper goggles, gloves, respirator, and clothing.

FYI:

Woodpeckers will peck on your walls for three reasons: One, They are looking for food. Two, they're making a nest. Three, they're defining their territory.

Carpenter bees do not eat wood but do feed on plant pollen and nectar. One of their favorite items to excavate is the rails and posts of oak split rail fences. They prefer pine, fir, cyprus, oak and redwood, especially if the wood is not covered with bark, is unpainted or unfinished.

Carpenter Ants do not eat the wood in which they nest, but chew it to create galleries and connecting tunnels. They nest in homes and buildings, in enclosed areas where the wood is damp, wet or decayed. If infestations grow, the carpenter ant colony may expand into sound wood.



6620 N CTH J - CATO - WI - 54230

www.rymarindustries.com

Email: rymar@rymarindustries.com

Call: 920-732-3909